



## QUICK USER GUIDE

Use shims to adjust the behavior of your hydrofoil by acting on the angle of incidence of the stabilizer:

1. Choose the right shim based on the desired angle of incidence
2. ***Use the screws sold with the stabilizer and the one given with the shims to make sure that the threads protude at least 6-7 mm***
3. Place the shim between the fuselage and the stabilizer
4. Tighten the two screws

## WARNING

***Make sure the screws do not push directly into the bottom of the fuselage holes.***